

Guide Formulation

Personal Care

Long-Lasting Silky Radiant CC Cream

(MJ13J_01A)

Raw Material/INCI Name	%w/w	Trade name/Supplier	Function
Phase A			
Methyl Trimethicone	5.00	SeraSense®SF MTM/KCC Beauty	Fast Absorption
Dimethicone	8.00	SeraSense®SF 5/KCC Beauty	Skin Conditioning
Phenyl Trimethicone	4.00	SeraSense®SF PTM/KCC Beauty	Aids Spreading
PEG-10 Dimethicone	3.00	SeraSol®SC 86A/KCC Beauty	W/O Emulsifier
Cyclopentasiloxane (and) Dimethicone/Vinyl Dimethicone Crosspolymer	2.00	SeraSilk®EL 63/KCC Beauty	Skin Feel
Squalane	5.00	Phytosqualane/Various	Emollient
CI 77492	0.27	Idacos Yellow Iron Oxide/Lehvoss	Pigment
CI 77491	0.073	Idacos Red Iron Oxide/Lehvoss	Pigment
CI 77499	0.038	Idacos Black Iron Oxide/Lehvoss	Pigment
CI 77891	2.00	Cosmetic Titanium Dioxide/Surfachem	Pigment
Mica (and) CI 77891	4.00	Timiron Super Red/Azelis (Merck)	Pigment
Disteardimonium Hectorite	0.50	Bentone 38V/Azelis (Elementis Speciality)	Thickener
Acrylates/Dimethicone Copolymer (and) Cyclopentasiloxane	2.00	SeraSense®AC 15/KCC Beauty	Flexible Film Former, long-wear
Phase B			
Aqua (Water)	To 100	-	Vehicle
Dipropylene Glycol	8.00	Various	Humectant
Sodium Hyaluronate (and) Aqua (Water)	10.00	HyaCare (1% Solution)/Surfachem	Skin Conditioning
Sodium Chloride	1.00	Sodium Chloride PVD/British Salt	Emulsion Stabiliser
Phase C			
Phenoxyethanol	0.40	S&M Phenoxyethanol/Schülke	Preservative
Caprylhydroxamic Acid (and) Caprylyl Glycol (and) Glycerin	0.40	Spectrastat/Azelis (Inolex)	Preservative
Parfum (Fragrance)	0.10	Vitamin 248 Fragrance/Givaudan	Fragrance

Method

Mix the ingredients of Phase A until homogenous

In a separate vessel, mix the ingredients of Phase B until homogenous. Add Phase B to A with stirring

Slowly add Phase C to A+B, with stirring



Scan me to find out more about KCC Beauty online!

Please note that the above formulation is only intended as a guide. It is not a commercial formulation and has not been tested as such. The formulation should be evaluated and modified for your own requirements before use. Also suggestions of uses should not be taken as inducements to infringe any particular patent.

Basildon Chemical Co. Ltd, Kimber Road, Abingdon, Oxfordshire, OX14 1RZ, UK

KCC Corporation, 1301-4, Seocho-Dong, Seocho-Gu, 137-703, Seoul, Korea

☎ +44 (0)1235 526677 | ✉ info@kccbeauty.com | 🌐 www.kcc-beauty.com