

Instant Wrinkle Corrector (SJ13F_07)

The wrinkle reduction ability of this formulation is thanks to **SeraSense® SP 13**; a spherical elastomer powder that gives a smooth-rolling effect. This is an easily dispersed material which creates a soft-focus effect and leaves the skin incredibly silky and smooth.

Raw Material/INCI Name	% w/w	Trade name/Supplier	Function
Phase A			
Dimethicone/Vinyl Dimethicone Crosspolymer	22.00	SeraSnow® SP 13/KCC Beauty	Wrinkle Filling/Soft Focus Effect/Powdery Feel
Phenyl Trimethicone	6.00	SeraSense® SF PTM/KCC Beauty	Solvent/Emollient
Cyclopentasiloxane	To 100	SeraSense® CM5/KCC Beauty	Solvent/Emollient
Tocopheryl Acetate	0.10	Various	Antioxidant
Phase B			
Mica (and) Titanium Dioxide	0.50	Flamenco Red 420C/BASF	Pigment
Parfum (Fragrance)	q.s.	-	Fragrance
Aqua (and) Butylene Glycol (and) Sodium Bicarbonate (and) Xanthan Gum Crosspolymer (and) Hydroxyethylcellulose	1.00	Quicklift/BASF	Skin Lifting

Typical Properties

Appearance:	Hazy, viscous gel
Viscosity @ 25°C:	646,000 - 874,000cP (Brookfield HBDV II, Sp6, 1rpm)
pH @ 25°C:	n/a

Method

Premix the ingredients of Phase A.

In the main vessel, add the ingredients of Phase B and mix until homogenous.

Add Phase A to B and mix until homogenous.

Check viscosity.



Scan me to find out more about KCC Beauty online!

Please note that the above formulation is only intended as a guide. It is not a commercial formulation and has not been tested as such. The formulation should be evaluated and modified for your own requirements before use. Also suggestions of uses should not be taken as inducements to infringe any particular patent.