

## Guide Formulation

### Personal Care

# Transparent Pore Primer (MJ16S\_04)

This primer has a very silky and smooth feeling. SeraSilk® EL 75 has a transparent appearance and gives a light, silky feel and pore coverage. SeraSense® SF MTM gives fast absorption and a smooth feel.

Raw Material/INCI Name	% w/w	Trade name/Supplier	Function
<b>Phase A</b>			
Methyl Trimethicone	To 100	SeraSense® SF MTM/KCC Beauty	Solvent/Emollient
Dimethicone (and) Dimethicone/Vinyl Dimethicone Crosspolymer	75.00	SeraSilk® EL 75/KCC Beauty	Instant Wrinkle Cover/Soft Focus Effect/Soft Touch Feeling
<b>Phase B</b>			
Mica (and) Titanium Dioxide	0.01	Timiron® Starluster MP-115/Merck	Aesthetics
Parfum (Fragrance)	q.s.	-	Fragrance

### Typical Properties

Appearance:	Transparent, viscous cream
Viscosity @ 25°C:	21,000 - 33,000cP (Brookfield LVDV II, LV-4, 6rpm)
pH @ 25°C:	n/a

### Method

Mix the ingredients of Phase A until homogenous.  
Add B to A with stirring.



Scan me to find out more about KCC Beauty online!

Please note that the above formulation is only intended as a guide. It is not a commercial formulation and has not been tested as such. The formulation should be evaluated and modified for your own requirements before use. Also suggestions of uses should not be taken as inducements to infringe any particular patent.

Basildon Chemical Co. Ltd, Kimber Road, Abingdon, Oxfordshire, OX14 1RZ, UK  
KCC Corporation, 1301-4, Seocho-Dong, Seocho-Gu, 137-703, Seoul, Korea

+44 (0)1235 526677 | [info@kccbeauty.com](mailto:info@kccbeauty.com) | [www.kcc-beauty.com](http://www.kcc-beauty.com)