

Illuminating Pore Cover Primer (MJ15M_01A)

This primer is easily absorbed into the skin with a non-greasy feel, so perfect for use under foundation. **SeraSilk® PD 69** is an blend of spherical elastomer powder and volatile fluid, giving a smooth-rolling effect, wrinkle cover and a matte finish. **SeraSense® AC 15** acts as a fixative, giving long-lasting coverage.

Raw Material/INCI Name	% w/w	Trade name/Supplier	Function
Phase A			
Caprylyl Methicone	5.00	SeraSense® SF CPM/KCC Beauty	Solvent/Emollient
Phenyl Trimethicone	3.00	SeraSense® SF PTM/KCC Beauty	Solvent/Emollient
PEG-10 Dimethicone	3.00	SeraSol® SC 86A/KCC Beauty	W/O Emulsifier
Cyclopentasiloxane (and) Cyclohexasiloxane (and) Dimethicone/Vinyldimethicone Crosspolymer	20.00	SeraSilk® PD 69/KCC Beauty	Wrinkle Cover/Soft-Focus Effect/Viscosity Modifier
Acrylates/Dimethicone Copolymer (and) Cyclopentasiloxane	0.50	SeraSense® AC 15/KCC Beauty	Fixative
Tocopheryl Acetate	0.10	Various	Anti-Oxidant
Disteardimonium Hectorite	0.30	Bentone 38V/Elementis Speciality	Thickener
Mica (and) Titanium Dioxide	3.00	Flamenco Red/Engelhard Corp.	Pigment
Phase B			
Aqua (Water)	To 100	-	Vehicle
Dipropylene Glycol	8.00	Various	Humectant
Sodium Chloride	1.00	Various	Emulsion Stabiliser
Phase C			
Phenoxyethanol	0.30	Various	Preservative
Caprylhydroxamic Acid (and) Caprylyl Glycol (and) Glycerin	0.30	Spectrastat/Inolex	Preservative
Parfum (Fragrance)	q.s.	-	Fragrance

Typical Properties

Appearance:	Beige, viscous emulsion
Viscosity @ 25°C:	37,500 – 50,000cP (Brookfield LVDV II, LV-4, 6rpm)
pH @ 25°C:	n/a

Method

Mix the ingredients of Phase A until homogenous.

In a separate vessel, mix the ingredients of Phase B.
Slowly add B to A with stirring.
Slowly add C to A+B with stirring.



Scan me to find out more about KCC Beauty online!

Please note that the above formulation is only intended as a guide. It is not a commercial formulation and has not been tested as such. The formulation should be evaluated and modified for your own requirements before use. Also suggestions of uses should not be taken as inducements to infringe any particular patent.